

Parametry pro naladění DVB-C (lokality: Ratíškovice, Lužice, Vracov, Těmice)

Frekvence: ____
Symbolová rychlost: 6900
Modulace: 64QAM

Frekvence: **514MHz (C26)**
Nova, Prima Family, Nova Cinema, Prima Cool, Nova HD



Frekvence: **522MHz (C27)**
ČT1 SM, ČT1 JM, ČT2, ČT4 Sport, ČT24 + rádia



Frekvence: **530MHz (C28)**
ČTHD, Óčko TV, Barrandov, Barrandov HD, TV Noe



Frekvence: **538MHz (C29)**
Prima Love, STV1, STV2 + rádia



Frekvence: **474MHz (C21)**
Prima Family HD, Prima Cool HD, UP FW Kaon



Frekvence: **482MHz (C22)**
TA3



Frekvence: **394MHz (S32)**
HBO, HBO2, HBO Comedy, HBO HD



Frekvence: **402MHz (S33)**
Cinemax, Cinemax 2, Disney Channel



Frekvence: **410MHz (S34)**

Spektrum, Discovery, Animal Planet, Viasat History, Viasat Explorer



Frekvence: **418MHz (S35)**

Universal Channel, CS Film, Eurosport, FishingHunting



Frekvence: **426MHz (S36)**

Nova Sport, Minimax, JimJam



Frekvence: **434MHz (S37)**

Sport1, Sport2, Sport5, AXN



Frekvence: **442MHz (S38)**

VH1, MTV CZ, Mezzo, BBC World, France24, CNN



Frekvence: **458MHz (S40)**

Leo TV

